



Electronic Accessories for VisiLED


Electronic Accessories specially developed for the VisiLED Controller MC 1500.



Footswitch, 400 020

Footswitch

- Enables the user to remotely switch between stored memory positions 1 through 4 to quickly change the stored illumination conditions.
- Allows the user to quickly and easily change to various illumination types by allowing total hand control under the microscope.



Flash Cable, 400 035

Flash Cable

- Allows the connection of the MC 1500 to a photo camera, CCD camera or other photographic equipment via an S contact.
- Facilitates externally triggered flash and trigger modes.



Converter Cable, 400 030

RS-232 USB 1.1 Converter Cable

- Connects the serial plug of the MC 1500 controller to the USB plug of a computer.
- Full USB 1.1 functionality will be maintained.
- Driver is included.

Electronic Accessories		
Description	Part No.	Length
Footswitch	400 020	
RS-232 USB 1.1 Converter Cable	400 030	1.5 meter (59")
Flash Cable spiral wound	400 035	500 - 1000 mm (20"-39")

Electronic Accessories for VisiLED

